

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9

FLOW OF DATA




FIG. 10

FLOW OF DATA




FIG. 11




FIG. 12

FLOW OF DATA







FIG. 13A







FIG. 13B







FIG. 14A







FIG. 14B

CONFIRMATION PRINT START PROCESSING







FIG. 15A






FIG. 15B




FIG. 16




FIG. 17




FIG. 18A





FIG. 18B



CONFIRMATION PRINT START PROCESSING

S10 SELECT AS PRINTER FOR USE IN
ACTUAL PRINTING

S11 SEND PRINT REQUEST PACKET

S12 INTERNAL STATUS IS SET TO IN
PRINT-REQUEST

S13 WAIT RESPONSE TO PRINT
REQUEST FROM PRINTER

S14 RECEIVE RESPONSE PACKET
FROM PRINTER

S15
INTERNAL STATUS
IS IN PRINT-REQUEST
AND RESPONSE PACKET TO
PRINT REQUEST
IS RECEIVED ?

NO

YES

S16 FETCH RESPONSE PACKET FROM
PRINTER INTO INTERIOR

POST PRINT DATA TRANSFER
UNIT ON PRINTER
COMMUNICATION INFORMATION S17

S1901 POST USER I/F UNIT
ON ADDITIONAL
INFORMATION

END

S18

TO PRINT
PROCESSING

S20

DISPLAY
PRINTER TO GUI





FIG. 19A

PRINTER RETRIEVAL RESPONSE PROCESSING






FIG. 19B

